

ランドリーLaundry



■使用方法

- ①硬貨を入れる ※投入された硬貨は返却されません。
- ②使用料金投入後10秒以内に、「洗濯槽シャワーボタン」を押します。
30秒間洗浄します。
※洗剤・ソフト剤が排出されるので、洗濯物・洗剤・ソフト剤は絶対に入れないでください。
- ③フタのロックが解除されてから洗剤を入れてください。
- ④洗濯物を入れ、ふたを閉じてください。
- ⑤ソフト剤を入れる場合
「ソフト剤投入」ランプの点滅中に「ふたロック解除」ボタンを押し、
ロック解除後ソフト剤を入れてふたを閉じてください。
(残り時間表示が13～11分の時)
- ⑥ゼロ表示で終了です。

■How to use the washing machines

- ① Insert coins
 - Please be aware that inserted coins cannot be refunded.
- ② To clean the inside of the washing machine drum, press the "Washing machine rinse" button (洗濯槽シャワーボタン) within 10 seconds of inserting coins. The drum will get rinsed out for 30 seconds.
 - Do not put laundry, detergent, or fabric softener into the drum before or during the "Washing machine rinse" cycle. If you do, your clothes will get dirty, and your detergent and fabric softener will get rinsed away.
- ③ Add detergent after the lid unlocks.
- ④ Load laundry and close the lid.
- ⑤ Add softener (optional)
 - When the "Add fabric softener" light (ソフト剤投入) begins flashing, press the "Unlock lid" button (ふたロック解除). After the lid unlocks, add fabric softener, and then close the lid.
 - Option becomes available when there are 13 to 11 minutes remaining.
- ⑥ All the washing cycles are complete when "0" is shown on the display screen.